

SECURITY+ V4 LAB SERIES

Lab 11: Configuring a RADIUS Server

Document Version: 2023-02-27

Material in this Lab Aligns to the Following			
CompTIA Security+ (SY0-601) Exam Objectives	3.8: Given a scenario, implement authentication and authorization solutions		
All-In-One CompTIA Security+ Sixth Edition ISBN-13: 978-1260464009 Chapters	24: Implement Authentication and Authorization		

Copyright © 2023 Network Development Group, Inc. www.netdevgroup.com

NETLAB+ is a registered trademark of Network Development Group, Inc.

KALI LINUX ™ is a trademark of Offensive Security.

Microsoft®, Windows®, and Windows Server® are trademarks of the Microsoft group of companies.

VMware is a registered trademark of VMware, Inc.

SECURITY ONION is a trademark of Security Onion Solutions LLC.

Android is a trademark of Google LLC.

pfSense® is a registered mark owned by Electric Sheep Fencing LLC ("ESF").

All trademarks are property of their respective owners.



Contents

ntroduction	3
Objective	
ab Topology	
_ab Settings	
L Configure RADIUS on Windows	
1.1 Add the Network Policy Role	
1.2 Configure the Network Policy Server	
PreeRADIUS on Ubuntu	



Introduction

In this lab, you will install, configure, and deploy a RADIUS server within the Windows and Linux operating systems.


Objective

In this lab, you will perform the following tasks:

- Set up and configure RADIUS on Windows
- Set up and configure RADIUS on Linux



Lab Topology





Lab Settings

The information in the table below will be needed in order to complete the lab. The task sections below provide details on the use of this information.

Virtual Machine	IP Address	Account (if needed)	Password (if needed)
Kali	203.0.113.2	kali	kali
pfSense	192.168.0.1	sysadmin	NDGlabpass123!
SecOnion	192.168.0.6	sysadmin	NDGlabpass123!
UbuntuSRV	172.16.1.10	sysadmin	NDGlabpass123!
WinOS	192.168.0.50	Administrator	NDGlabpass123!




1 Configure RADIUS on Windows

1.1 Add the Network Policy Role

In this task, you will add the role of *Network Policy Server* to the *WinOS* server. You will then add the *Network Policy and Access Services Tools*.


1. Launch the **WinOS** virtual machine to access the graphical login screen.



- 2. While on the splash screen, focus on the *NETLAB+* tabs. Click the dropdown menu for the **WinOS** tab and click on **Send CTRL+ALT+DEL**.
- 3. Log in as Administrator using the password NDGlabpass123!.




4. Once logged in, click the **Server Manager** icon to launch it. In the *Server Manager* window, click on **Manage** in the top-right corner and select **Add Roles and Features**.






5. Notice the *Add Roles and Features Wizard* appears. On the *Installation Type* step, keep the default setting of **Role-based or feature-based Installation** and click **Next**.




6. On the Server Selection step, select the WinOS.netlab.local server from the pool and click Next.






7. On the *Server Roles* step, check the checkbox for **Network Policy and Access Services** and notice a pop-up window appears. Click the **Add Features** button.




8. Back on the main wizard window, ensure that **Network Policy and Access Services** is checked, and click **Next.**






9. On the Features step, leave the defaults and click Next.




10. On the Network Policy and Access Services step, review the information and click Next.






11. On the Confirmation step, click Install to finish the installation of the Network Policy Server.




12. The installation will take about 3 minutes. After the install is complete, click Close.






1.2 Configure the Network Policy Server


1. Back on the Server Manager window, navigate to Tools > Network Policy Server.



2. In the *Network Policy Server* window, in the left pane, right-click on **NPS (Local)** and select **Register Server in Active Directory.**




3. When prompted to authorize, click **OK** to continue.





4. Click **OK** again to confirm that the system is now authorized.



5. Expand the **RADIUS Clients and Servers** inventory object, right-click on **RADIUS Clients** and click **New.**






6. In the New RADIUS Client window, fill in the following information:

a. Friendly name: SecOnionb. Address: 192.168.0.6

c. Shared secret: password123

d. Confirm shared secret: password123




- 7. Once the configurations are made, click OK.
- 8. Select **RADIUS Clients** from the left pane and verify that the *SecOnion Client* appears in the right pane and that it is enabled.






9. Now it is time to create a new network policy. In the left pane, expand **Policies**, right-click on **Network Policies** and select **New**.




10. In the *New Network Policy* window, type Remote Access RADIUS in the *Policy name* text field and click **Next.**







11. On the Specify Conditions step, click the Add button.



12. In the Select condition window, scroll down and select Access Client IPv4 Address and click Add.




13. When prompted for an IPv4 address, type 192.168.0.6 and click OK.






14. Back on the Specify Conditions step, ensure that the new condition is listed and click Next.




15. On the Specify Access Permission step, leave Access granted selected and click Next.






16. On the Configure Authentication Methods step, leave the default settings and click Next.




17. On the Configure Constraints step, leave the default settings and click Next.






18. On the Configure Settings step, leave the defaults and click Next.




19. On the Completing New Network Policy step, leave the defaults and click Finish.





20. Back on the *Network Policy Server* window, in the left pane, click on **Network Policies** and confirm the new policy appears in the right pane.




21. This section is now complete. Proceed to the next section to configure RADIUS on the Ubuntu system.





2 FreeRADIUS on Ubuntu

1. Launch the **UbuntuSRV** virtual machine to access the graphical login screen.



2. Log in as **sysadmin** using the password **NDGlabpass123**!.





3. Click the **Terminal** icon in the dock to start *Terminal*.



4. In the new *Terminal* window, type the command **service freeradius status** to check the status of the service. It should say *inactive*. Press **q** on the keyboard to get out of the status check.




5. We are going to create a test account to locally test the RADIUS server. Type the command below in the *Terminal*. Enter NDGlabpass123! when prompted for a password.


sudo nano /etc/freeradius/3.0/mods-config/files/authorize

```
http://wiki.freeradius.org/
http://networkradius.com/doc/
sysadmin@ubuntusrv:~$ sudo nano /etc/freeradius/3.0/mods-config/files/authorize
[sudo] password for sysadmin:
```


6. Once in the editor, press **Enter** to insert a newline at the top of the file. Then add the user info by typing: testing Cleartext-Password := "password"



7. Then, press **Ctrl** + **S** to save the file and **Ctrl** + **X** to quit the editor.




8. Start a new *Terminal* by right-clicking the **Terminal** icon in the dock and selecting **New Window**.





9. Rearrange the two windows to make them side-by-side.



10. RADIUS is mostly used for *Business Wireless Access Point* authentication. It is an alternative method to Active Directory. In this lab, we are only going to test and learn the functionality of RADIUS rather than configure it.

In the first *Terminal* window, type the command **sudo freeradius** –X and press **Enter** to run it. The -X option will run the *freeradius* service in debugging mode. Enter **NDGlabpass123!** when prompted for the password.

```
[sudo] password for sysadmin:
sysadmin@ubuntusrv:~$ sudo freeradius -X
```

11. When you see the *Ready to process requests* prompt, it means the RADIUS server is up and running. And for local testing, it is bound to port **18120.**

```
}
Listening on auth address 127.0.0.1 port 18120 bound to server inner-tunnel
Listening on auth address * port 1812 bound to server default
Listening on acct address * port 1813 bound to server default
Listening on auth address :: port 1812 bound to server default
Listening on acct address :: port 1813 bound to server default
Listening on proxy address * port 56242
Listening on proxy address :: port 56418

Ready to process requests
```

12. Now switch to the other *Terminal* window. Enter the command radtest —h to bring up the help page.



13. Based on the help info, the command we will be using is:

```
radtest testing password 127.0.0.1 18120 testing123
```

14. If you see the result showing *Received Access-Accept*, it means the RADIUS server is working.

15. And you should see the response scrolling in the other window.

```
(0)
      } # Auth-Type PAP = ok
(0) # Executing section post-auth from file /etc/freeradius/3.0/sites-enabled
/default
(0)
        if (session-state:User-Name && reply:User-Name && request:User-Name &
(0)
& (reply:User-Name == request:User-Name))
(0)
        if (session-state:User-Name && reply:User-Name && request:User-Name &
& (reply:User-Name == request:User-Name)) -> FALSE
(0)
        update {
(0)
          No attributes updated for RHS &session-state:
(0)
        } # update = noop
(0)
        [exec] = noop
(0)
        policy remove_reply_message_if_eap {
(0)
          if (&reply:EAP-Message && &reply:Reply-Message) {
(0)
          if (&reply:EAP-Message && &reply:Reply-Message) -> FALSE
          else {
            [noop] = noop
(0)
          } # else = noop
        } # policy remove_reply_message_if_eap = noop
(0)
      } # post-auth = noop
(0) Sent Access-Accept Id 235 from 127.0.0.1:1812 to 127.0.0.1:54668 length 0
(0) Finished request
Waking up in 4.9 seconds.
(0) Cleaning up request packet ID 235 with timestamp +532
Ready to process requests
```

16. The lab is now complete; you may end your reservation.